



## Ventech VTM190 Roof Fan


Mounting details & wiring diagrams




Single speed fan curve




Three speed fan curve



VTM190-1 B2M190-70 Single speed wiring



VTM190–3 B2M190-70-3 Three speed wiring



## Warning

Ensure that fan is switched off from supply mains before removing guard.

Precautions must be taken to avoid back-flow of gases into room from open flue of gas or other fuel-burning appliances.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons.

Means for disconnection must be incorporated in fixed wiring in accordance with wiring rules

Appliance not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of appliance by person responsible for their safety.

Children should be supervised to ensure they do not play with appliance.

